

VCRWorX

Smarter
First in Fieldbus

MAY / 06

VCRWorX

VERSION 8



USER'S MANUAL

VCRWorX



PVI EWX ME



Specifications and information are subject to change without notice.
Up-to-date address information is available on our website.

web: www.smar.com/contactus.asp

TABLE OF CONTENTS

INTRODUCTION TO VCRWORX DATA REPLAY.....	8
VCRWORX TOOLS	8
VCRWORX HISTORICAL DATA REPLAY	8
VCRWORX ALARM DATA REPLAY	9
VCRWORX QUICK START EXAMPLE	9
REPLAYING DATA IN THE VCRWORX CONTROL PANEL.....	14
VCRWORX CONTROL PANEL.....	16
LAUNCHING THE VCRWORX CONTROL PANEL.....	17
VCRWORX CONTROL PANEL INTERFACE.....	17
CONTROL PANEL TIME FIELD	18
SETTING RANGES FOR DATA REPLAY	18
SETTING THE REPLAY SCAN RATE.....	19
REPLAY CONTROL BUTTONS	19
CONTROL PANEL SKINS.....	20

INTRODUCTION TO VCRWORX DATA REPLAY

VCRWorX is a powerful tool in ProcessView that enables the replay and reanimation of graphical, historical and alarm data. Features of VCRWorX include:

- Replay of OPC data.
- Reanimation of graphics.
- Re-plotting of trends.
- Replay of alarms.
- See what the operator saw through replay of graphical displays.
- VCRWorX Control Panel with customizable skins/layouts.
- Change the replay speed.
- Specify time and date ranges for data replay.
- Search for key events, tags, and expressions.
- Customize the layout and appearance using skins.

VCRWorX Tools

There are two main tools that you must use to configure and view VCRWorX data replay:


- **VCRWorX Control Panel:** This is the runtime user interface in GraphWorX, TrendWorX, and AlarmWorX that enables you to replay and view your historical data. This document primarily describes how to operate the VCRWorX Control Panel.
- **Unified Data Configurator:** VCRWorX replays historical data from the active TrendWorX Logger and AlarmWorX Server configuration databases. But before you can playback data using the VCRWorX Control Panel, you first must configure your data-logging settings in the Unified Data Configurator. The **Unified Data Configurator** enables you to select existing configuration databases or create new databases for VCRWorX data replay. You can also create and configure alarm tags and trend pens. For more information about the Unified Data Configurator, please see the Unified Data Configurator help documentation.

VCRWorX Historical Data Replay

An overview of VCRWorX historical data replay is shown in the figure below. VCRWorX replays historical data from the active TrendWorX Logger configuration database, which is configured using the Unified Data Configurator.

✓ Historical Data Replay

- VCRWorX Feature
- VCRWorX WEBHMI Integration




Overview of VCRWorX Historical Data Replay

VCRWorX Alarm Data Replay

An overview of VCRWorX alarm data replay is shown in the figure below. VCRWorX replays alarm data from the active AlarmWorX Server configuration database, which is configured using the Unified Data Configurator.

NOTES
Although the AlarmWorX Logger can log data to multiple databases, VCRWorX can only replay alarms from one database.
VCRWorX alarm replay does not support alarms coming from Oracle databases.
VCRWorX alarm replay does not work with alarm databases that were created using versions of ProcessView prior to version 8.0.



Overview of VCRWorX Alarm Data Replay

VCRWorX Quick Start Example

The ProcessView installation provides a **VCRWorX_Example.gdf** as an example of how to set up VCRWorX data replay in a GraphWorX display:

1. Browse to the **C:\Program Files\Smar \ ProcessView \ Examples\VCRWorX Examples** directory and open the **VCRWorX_Example.gdf** file. The file opens in GraphWorX, as shown in the figure below.

VCRWorX_Example.gdf - GraphWorX by Smar


File View Tools Configure Help

quarta-feira, 0 dezembro 28, 2005 11:37:43

system 002 smar FIRST IN FIELDBUS

VCRWorX Quick Start Tutorial

1. Start the TrendWorX Logger Configurator
2. Load the sample Trend Logger configuration:
 - a) Click on "File" --> "Open"
 - b) C:\Program Files\Smr ProcessView\Examples\VCRWorX Examples\VCRConfig.mdb
 - c) Double click on VCRConfiguration on the right hand side
 - d) Click on "Make Active" and then close the window
3. Put this display into runtime (if it isn't already), and then click on "Tools" --> "VCRWorX"
4. Click on the time field and enter a date of 1-JUNE-2004 and a time of 10:00:00 AM.
5. Finally, press the play button and watch the process points and ActiveX's update!



File View Tools Configure Help

Security Logn...
Set Working Directory...
VCRWorX

Insert the time: 10:00:06 AM
Insert the date: 06/01/2004

Watch Closely!

SimulatePLC.Ramp *****
SimulatePLC.Random *****
SimulatePLC.Sine *****

Numeric ActiveX

0 25 50 75 100

VCRWorX Example in GraphWorX

2. Start the TrendWorX Logger Configurator from the Windows **Start** menu by selecting **Programs > Smar ProcessView > ProjectWorX > TrendWorX Configurator**.
3. This opens the TrendWorX Logger Configurator. Open a configuration database by selecting **Open** from the **File** menu, as shown in the figure below.


File Edit View Go Action Tools Help

New Ctrl+N
Open... Ctrl+O
Save As...
Connection Properties...
CSV Export...
CSV Import...
XML Export...
XML Export Schema...
XML Import...
XML Validate...
Make Active
1 VCRConfig.mdb
2 TwxLogger Test.mdb
3 Twx32DemoCfg.mdb
4 C:\Program Files\...\Twx32.mdb
Exit

Configuration	Node name	Use UTC Time	Modified
	(local)	No	11/24/2003 12:49:51 PM


Opening a Trend Logger Configuration Database

- Browse to the **C:\Program Files\Smar\ProcessView\Examples\VCRWorX Examples** directory and select the **VCRConfig.mdb** database, as shown in the figure below.




Opening the Sample VCRWorX Trend Logger Configuration

- Go to the **VCRConfiguration** under the **Configurations** tree control, as shown in the figure below. Click the **Make Active** button to activate the configuration.




Activating the VCR Configuration

- Select **Exit** from the **File** menu to close out of the TrendWorX Configurator.
- Put the **VCRWorX_Example.gdf** display file into runtime by clicking the **Runtime** menu in GraphWorX, as shown in the figure below.




Starting Runtime Mode

8. Select **VCRWorX** from the GraphWorX **Tools** menu, as shown in the figure below.




Launching the VCRWorX Control Panel

9. This opens the **VCRWorX Control Panel**, as shown in the figure below.



VCRWorX Control Panel

10. Click on the time field. This opens the **Insert Time/Date Values** pop-up dialog. For the date, enter December 28, 2005. For the time, enter 09:26:00 AM, as shown in the figure below. Click **OK**.



Entering a Start Date and Start Time

11. Press the **Play** button on the VCRWorX Control Panel, as shown in the figure below.



Starting VCRWorX

12. The GraphWorX display goes into VCRWorX historical replay mode based on the time and date you provided. Now you can see the process point values and ActiveX controls update in the GraphWorX display, and you can see the time/date field of the VCRWorX Control Panel in replay, or "playback," mode, as shown in the figure below.



VCRWorX Control Panel in Replay Mode


Replaying Data in the VCRWorX Control Panel

Once you have configured your database connections and tags using the Unified Data Configurator, you are ready to prepare for VCRWorX data replay:

1. Start data logging in the AlarmWorX Logger Configurator and the TrendWorX Logger Configurator. It is recommended that you let the data loggers run for at least 30 minutes so that you will have adequate data for data logging. To replay VCR data, there should be a substantial time delay between the current time and the VCRWorX replay time. For example, if you start data logging at 11 AM, you cannot start replaying data until 11:20 AM. This "safe" delay time is twice the block size specified in the Unified Data Configurator. The default block size is 10 minutes. So the safe delay should be at least 20 minutes. This is for shorter logging rates (logging to disk less than 5 minutes). For longer logging rates (more than 5 minutes) the safe delay should be twice the block size plus the logging rate. For example, if you are logging data every 15 minutes, then the safe delay should be at least $20+15 = 35$ minutes. For more information please refer to the AlarmWorX Logger Configurator and TrendWorX Logger Configurator help documentation.


NOTE

Although the AlarmWorX Logger can log data to multiple databases, VCRWorX can only replay alarms from one database. The **Alarm Snapshots** section of the **Database Logging** tab in the AlarmWorX Logger Configurator, shown in the figure below, allows you to create a "snapshot" table that can be used to replay alarm data in VCRWorX. In the **Snapshots Period** field, specify how often (in hours) a snapshot table can be created. A snapshot period value of "0" (zero) means that no snapshot table will be created. For VCRWorX data replay to work with alarms, the value of the snapshot period must be greater than "0." For more information please refer to the AlarmWorX Logger Configurator help documentation.



Alarm Snapshots in Alarm Logger Configurator

2. Start GraphWorX and open the .gdf file that you configured in the Unified Data Configurator.
3. Start runtime mode in GraphWorX.
4. Select **VCRWorX Replay** from the GraphWorX **Tools** menu, as shown in the figure below.




Launching the VCRWorX Control Panel

5. This opens the **VCRWorX Control Panel**, as shown in the figure below.



VCRWorX Control Panel

6. Click on the time field. Enter a date and time from which to begin the data replay. Click **OK**.



Entering a Start Date and Start Time

7. Press the **Play** button on the VCRWorX Control Panel, as shown in the figure below.



Starting VCRWorX Replay

8. The GraphWorX display goes into VCRWorX historical replay mode based on the time and date you provided. Now you can see the process point values and ActiveX controls update in the GraphWorX display, and you can see the time/date field of the VCRWorX Control Panel in replay, or "playback," mode, as shown in the figure below.

NOTE

For more information about the VCRWorX Control Panel, please see the VCRWorX help documentation.



VCRWorX Control Panel in Replay Mode


NOTE

If you want to replay data from a remote VCRWorX node, you must add the name of the VCRWorX server computer in front of the name of the tag that you want to replay. This applies to OPC Data Access tags as well as trends. This does not apply to alarms.

VCRWorX Control Panel

The VCRWorX Control Panel, shown in the figure below, is the user interface that enables you to configure your historical data replay time and date settings. You can:


- See what the operator saw through replay of graphical displays.
- Specify time and date ranges for replay.
- Fast forward and rewind.
- Change the replay speed.
- Search for key events, tags, or expressions.
- Customize the layout and appearance using skins.



VCRWorX Control Panel

Launching the VCRWorX Control Panel

The VCRWorX Control Panel can be launched from the GraphWorX, AlarmWorX, and TrendWorX containers during runtime mode. Select **VCRWorX Replay** from the **Tools** menu, as shown in the figure below.




Launching the VCRWorX Control Panel

VCRWorX Control Panel Interface

The VCRWorX Control Panel, shown in the figure below, contains the following user interface components:

- **Time Field:** Displays the current mode (e.g. Play, Stop, Fast Forward, Rewind, Step, Pause, etc.). Clicking on this field enables you to specify a start date and start time for data replay.
- **Status Bar:** Indicates live mode or playback mode.
- **Menu Buttons:** Allow you to close or minimize the Control Panel, open the online Help, or switch between normal mode and "micro" mode.
- **Load Skin Button:** Enables you to select a skin to change the Control Panel appearance.
- **Replay Control Buttons:** Allow you to Play, Stop, Rewind, Fast Forward, Step, and Slow down the replay display.
- **Search Button:** Specifies the time/date and/or expression range settings for data replay.
- **Settings Button:** Specifies the scan rate for data replay.



VCRWorX Control Panel


To conserve space in your display, you can switch to "micro mode" by clicking the **Micro Mode** menu button



Micro Mode

Control Panel Time Field

Clicking on the time field opens the **Insert Time/Date Values** pop-up dialog. Enter a start date and time for data replay, as shown in the figure below. Click **OK**.



Entering a Start Date and Start Time


Setting Ranges for Data Replay

Click the **Search** button to specify the start time/date and end time/date settings for data replay, as shown in the figure below. You can also select an OPC tag range.



Replay Range Settings

Clicking the ... button opens the **Select Date/Time Ranges** dialog box, as shown in the figure below. To select an OPC Tag, click the ... button and select a tag from the Unified Data Browser. The tag name appears in the **Select OPC Tag** field, as shown in the figure below. Once you have chosen a tag, clicking the **Retrieve Ranges** button automatically displays the start date/time and end date/time information for the tag.



Selecting Time and Date Ranges

Setting the Replay Scan Rate

Click the **Settings** button to specify the scan rate for data replay, as shown in the figure below. Choose a scan rate from the drop-down list, and then click the check mark button. The scan rate determines the frequency (in milliseconds) of data updates during replay mode.

NOTE

The first value in the list is a custom value that you can type in. All other values in the list are fixed scan rate frequencies.



Selecting a Scan Rate

Replay Control Buttons

The replay control buttons are similar to the buttons on a VCR or DVD player control console. The buttons allow you to Play, Stop, Rewind, Fast Forward, Step, and Slow down the replay display, as shown in the figure below:


- **Play:** Switches the display to replay (playback) mode.
- **Stop:** Switches the display back to live (real-time) runtime mode.
- **Fast Forward:** Speeds up the display in replay mode.
- **Slow Motion:** Slows down the display in replay mode.
- **Reverse:** Rewinds the display in replay mode.
- **Pause:** Stops the display in replay mode.
- **Step:** Moves the display forward in one-second intervals while in pause mode.



Replay Control Buttons on the VCRWorX Control Panel



Control Panel Skins

The appearance of the VCRWorX Control Panel appearance is customizable. You can choose from several different skins. To select a skin, click the load skin button, as shown in the figure below.



Loading a Skin

Select from one of the following skins, which change the color, style, and layout of the Control Panel. The Processview VCRWorX skin files are installed in the **C:\Program Files\Smart\ProcessView\VCRWorX32Skins** directory.



VCRWorX Control Panel Skins

